LEKATO TANK PRO_2026_10_15_V35 Release Notes

1.Equipped with the latest version of the NAM loader, and compatible with native NAM A2-Lite files.

2.Added 12 white-box DS.

3.Upgraded input gain and level display.

4.Optimized model display.

5.Optimized Looper recording and operation.

6.Optimized external expression pedal control.


7.fixed some bugs.

Firmware Update Procedure

1. Extract the file compatible with your operating system (use .zip for Windows and .dmg for macOS)
2. Connect the included USB cable between your computer and the effects pedal while powering on the device.


3. launch the Device Firmware Updater (M-UPGRADE)

Waiting for a device to connect




.

The device name and version number will be displayed once the connection is successful.



4. Open the **Select Firmware** option and select the firmware file **LEKATO TANK PRO_035.fwsc** from the installation package.



5. Select the **Update Firmware** option to start the upgrade.